


# Classroom Technology Use Guide



Speaker Volume Control

Projector ON/OFF Button

Output Selector Buttons



- Turn ON PC prior to turning ON projector
- Leave PC ON—Turn monitor OFF
- Use VCR/DVD toggle button on unit to switch between DVD and VCR
- Keep remote control inside lectern when not in use
- Please lock-up/secure equipment and room
- Report problems via a work order at <http://helpdesk.waketech.edu> (Please use Projector (Data/Computer) problem type and state if the equipment is housed in the lectern) or by calling the Helpdesk 662-4357

